

Detroit Parcel Survey – Field Surveyor Training Overview

The following pages are an overview of the initial Field Surveyor Training. They are intended as a reference in the field. Below are two example survey sheets. The following pages contain slides from the original training and are useful if you have forgotten any definitions.

Survey Instrument Template

Pre-Populated Sheets should be filled out as done below.

SURVEY DATE: 8/21 SURVEYOR: Lewis Cass EVEN A-13

* ADDRESS NEW	Street	Address	TYPE	CONDITION	VACANCY	VOD	FIRE	VACANT LOT
	APPOLINE	20524	S	1				
	BIRWOOD	20506	S	1				
<u>20516</u>	BIRWOOD	20524	S	2	1			
	BIRWOOD	20524	S	1				
	BIRWOOD	20530	S	1				2
<u>+ 20518</u>	MANOR	20516	D	1				
	MANOR	20524	S	4	1	1		
	MENDOTA	20516	M					1
	MENDOTA	20520	M	2				
	MEYERS	20520	A	1				
	MONTE VISTA	20516	M D	2				
<u>20520</u>	PINEHURST	20516	S	3	2			
	PINEHURST	20526	S	4	1	1	1	
	STEEL	20526	C					

Leave Blank for Commercial Catchall
of non-residential

Blank Sheets are provided at the end of each grid section for unaccounted for properties. Fill them out as done below.

Survey Date: 9/2 Surveyor: Lewis Cass Map #: B-1

Street Name	Address	Type	Condition	Vacancy	VOD	Fire	Vacant Lot
<u>E WARREN</u>	<u>312</u>	<u>S</u>	<u>1</u>				
<u>"</u>	<u>314</u>	<u>S</u>	<u>1</u>				<u>1</u>
<u>WOODSTOCK</u>	<u>2741</u>	<u>S</u>	<u>1</u>				
<u>↓</u>	<u>2743</u>	<u>S</u>	<u>1</u>				
	<u>2747</u>	<u>S</u>	<u>1</u>				<u>2</u>